

EX-2001

Racer Plus



USER INSTRUCTIONS

© Excell Precision Limited 2004. All rights reserved Worldwide.

The information contained herein is the property of Excell Precision Limited and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorised by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.



TABLE OF CONTENTS

SAFETY.....3

CHAPTER 1 SPECIFICATIONS4

CHAPTER 2 OPERATION GUIDE.....5

CHAPTER 3 FRONT AND REAR PANEL7

 3-1 FRONT PANEL.....7

 3-2 REAR PANEL.....8

CHAPTER 4 INSTALLATION9

 4-1 LOAD CELL9

 4-2 INDICATOR INSTALLATION AND DIMENSIONS.....9

CHAPTER 5 CAPACITY CALIBRATION.....11

 5-1 PARAMETER SETTING.....11

 5-1-1 Flow Diagram.....11

 5-1-2 Description.....12

 5-2 CALIBRATION SETTING14

 5-2-1 Calibration Procedure14

 5-2-2 Zero Calibration14

 5-2-3 Weight Calibration.....14

 5-2-4 Linearity Calibration15

 5-3 PASSWORD SETTING18

 5-4 ERROR MESSAGES19

CHAPTER 6 ANIMAL SCALE FUNCTION SETTING.....20

CHAPTER 7 INTERFACES21

 7-1 OP-01 RS-422 & RS-485 INTERFACE21

 7-2 OP-02 PARALLEL BCD OUTPUT24

 7-3 OP-03 ANALOGUE CURRENT / VOLTAGE OUTPUT INTERFACE.....26

 7-4 OP-05 PARALLEL PRINTER OUTPUT & RS-232 & CURRENT LOOP ...27

 7-5 OP-06 RS-232 & CURRENT LOOP30

 7-6 OP-07 RS-232, CURRENT LOOP & DATA CLOCK OUTPUT31

 7-7 OP-08 CONTROL I/O (2I/4O) INTERFACE32

CHAPTER 8 MAINTENANCE36

 8-1 RESET ALL PARAMETERS BACK TO DEFAULT36

 8-2 RESET GENERAL FUNCTION PARAMETERS BACK TO DEFAULT36

 8-3 SELF-DIAGNOSIS MODE.....36

 8-3-1 7 Digit Display and LED Status Light Diagnosis37

 8-3-2 Keyboard and Calibration ON / OFF Switch Diagnosis37

 8-3-3 RS-232 Serial Output / Input Interface Diagnosis (OP-06)37



| | | |
|---------------------------------------|---|-----------|
| 8-3-4 | BCD Parallel Output Interface Diagnosis (OP-02) | 37 |
| 8-3-5 | Analogue Current Output Interface Diagnosis (OP-03) | 38 |
| 8-3-6 | Parallel Printer Interface Diagnosis (OP-05) | 38 |
| 8-3-7 | Main Board EEPROM Memory Diagnosis | 38 |
| 8-3-8 | OP-08 Control I /O (2I /4O) Diagnosis | 38 |
| CHAPTER 9 FUNCTION TABLE | | 39 |
| 9-1 | GENERAL FUNCTION | 39 |
| 9-2 | OP-01, OP-06, OP-07 INTERFACE FUNCTION | 40 |
| 9-3 | OP-02 BCD OUTPUT INTERFACE FUNCTION | 41 |
| 9-4 | OP-03 ANALOGUE OUTPUT INTERFACE FUNCTION | 41 |
| 9-5 | OP-05 PARALLEL PRINTER OUTPUT INTERFACE FUNCTION | 42 |
| 9-6 | OP-08 CONTROL I /O (2I /4O) INTERFACE FUNCTION | 43 |



! SAFETY

- & Disconnect the main power supply before opening the indicator housing or installing / un-installing the instrument.
- & Keep the instrument in a cool dry place. Do not store it at high temperatures.
- & The operating ambient temperature range is -10°C ~ +40°C.
- & F.G. is the ground (electrical earth) connection. (Ground impedance < 100Ω)
Avoid connecting the ground connection with other equipment. The indicator must always be connected to the electrical ground (earth) for safe operation.



CHAPTER 1 SPECIFICATIONS

ANALOG DATA

| | | |
|------------------------------|------|--|
| Input sensitivity | | 0.12 $\mu\text{V}/\text{D}$ or more |
| Max. load cell input voltage | | -1mV~16mV |
| Load cell excitation | | DC 5V |
| Load cell current | | 120mA (8- 350 Ω load cells) |
| Temperature coefficient | Zero | -14.49 ppm/ $^{\circ}\text{C}$ (-10 $^{\circ}\text{C}$ ~40 $^{\circ}\text{C}$) |
| | Span | -1.65 ppm/ $^{\circ}\text{C}$ (-10 $^{\circ}\text{C}$ ~40 $^{\circ}\text{C}$) |
| Non-linearity | | $\pm 0.002\%$ FS |
| Input noise | | 8nV/ $\sqrt{\text{Hz}}$ f = 10KHz |
| Input impedance | | 250G Ω |
| Internal resolution | | 520000 |
| Max. display resolution | | -999999~999999 |
| Conversion rate | | 100 times/sec (max.) |

DIGITAL DATA

| | | |
|-------------------------------|--|---|
| Display section | | 7 digits, red LED, 20mm (0.8"), 7-segment |
| Status display section | | 6 character display, red LED |
| Display frequency (times/sec) | | Selectable, Max 50 |
| Display range | | -999999 to 999999 |
| Min. division | | 1, 2, 5, 10, 20, 50 |
| Status display | | Power, Zero, Motion, Gross, Net, Tare |
| Decimal point | | Selectable 0, 0.0, 0.00, 0.000, 0.0000 |

GENERAL SPECIFICATIONS














| | | |
|-----------------------------|--|--|
| Power requirements (AC/W) | | AC100V~240V -15%~+10% 10W |
| Operating temperature range | | -10 $^{\circ}\text{C}$ ~+40 $^{\circ}\text{C}$ |
| Operating humidity range | | <85% R.H |
| Physical dimensions | | 210(W) \times 108 (H) \times 207(D) |
| Weight | | About 1.7 kg |

OPTIONS

| |
|---|
| OP-01 RS422 / RS-485 |
| OP-2-1 Parallel BCD Output (TTL) |
| OP-2-2 Parallel BCD Output (O.C.) |
| OP-03 Analog Output (4 - 20mA) |
| OP-05 Parallel Printer Output / RS232C & Current Loop |
| OP-06 RS-232C & Current Loop |
| OP-07 RS-232C & Current Loop & Data Clock Output |
| OP-08 Control I / O (2I / 4O) |



CHAPTER 2 OPERATION GUIDE

| FUNCTION | OPERATION PROCEDURE | DESCRIPTION |
|---|--|--|
| General function setting | Press and hold the  key, then press the  | Refer to Chapter 9 Functions Table to set FUNC. 0 ~ FUNC. 7 |
| Capacity parameter setting | Switch the capacity calibration switch to "ON" and then press the  | Set the parameter for decimal point, max. capacity, min. division, zero tracking, unstable detection Refer to < 5-1 > Parameter Setting |
| Calibration | Switch the capacity calibration switch to "ON" and then press the  | Calibration procedures. Refer to < 5-2 > Calibration Setting |
| Self-diagnosis mode | Turn on the indicator, press and hold  and  the indicator starts the self-test procedure. | Refer to < 8-3 > Self-diagnosis Mode for details |
| Reset all parameters back to default | Switch the calibration switch to "ON", turn on the indicator, press and hold  and  while the indicator is in the self-testing sequence | Refer to < 8-1 > Reset All Parameter Back to Default |
| Reset general function parameter back to factory standard setting | Turn on the indicator, press and hold  , followed by pressing  while the indicator is in the self-testing sequence | Refer to < 8-2 > Reset General Function Parameter Back to Default |
| Display software version | Turn on the indicator, press and hold the  while the indicator is in the self-test sequence | The main display section displays the software version, press any key to exit |
| Function parameter setting | Press and hold  , followed by pressing  | Hi, Lo, Zero Band parameter setting |



4 Operation of Keys in the Setting Mode



⇒ Cycles the flashing character from 0 to 9



⇒ Shifts the flashing character to the left



⇒ Cycles the flashing character from 9 to 0



⇒ Save data



⇒ Shifts the flashing character to the right




⇒ Quit / Exit



CHAPTER 3 FRONT AND REAR PANEL

3-1 FRONT PANEL



1 MAIN DISPLAY

- Displays gross weight or net weight

2 STATUS INDICATION LIGHTS

- ☀ POWER : Power Indication
- ☀ ZERO : Zero status indication
- ☀ MOTION : Unstable weighing indication
- ☀ GROSS : Main display section currently displays gross wt.
- ☀ NET : Main display section currently displays net wt.
- ☀ TARE ENTERED : Tare indication

3 KEYS

- | | |
|--------------------|---|
| STANDBY OPERATE | 1) Standby mode ON/OFF 2) When setting the parameter or calibration, it works as quit or exit from setting |
| ZERO + | 1) Sets weight back to zero 2) When setting the parameter or calibration, it cycles from 0 to 9 |
| TARE - | 1) Tare function 2) When setting the parameter or calibration, it cycles from 9 to 0 |
| GROSS NET ← | 1) Switches between gross wt. / net wt. on the main display 2) When setting the parameter or calibration, it shifts the flashing character to the left |
| PRINT → | 1) Manually output serial / parallel data 2) When setting the parameter or calibration, it shifts the flashing character to the right |
| F n | 1) Weight accumulation, sub-total function (for OP-05) 2) Sets capacity parameter |
| C A L | 1) Weight accumulation, grand-total function (for OP-05) 2) Capacity calibration |
| ENTER ← | Confirmation key |



4 CAPACITY PARAMETER & CALIBRATION SWITCH




Loosen the black plastic screw and open the square cap on the front panel.

Slide the switch to the left is "ON"

Slide the switch to the right is "OFF"

3-2 REAR PANEL




1. AC power in terminal
2. Fuse 250V / 0.5A
3. Load cell connector
4. Optional interface location (if fitted)
5. Control I/O Interface location



CHAPTER 4 INSTALLATION

4-1 LOAD CELL



Four-wire (five-wire) load cell


- Pin 1 & 2 short, connected to EXC+
- Pin 3 & 4 short, connected to EXC-
- Pin 5 connected to SIG+
- Pin 6 connected to SIG-
- Pin 7 connected to the Shield

Six-wire (seven-wire) load cell

- Pin 1 connected to EXC+
- Pin 2 connected to SEN+
- Pin 3 connected to EXC-
- Pin 4 connected to SEN-
- Pin 5 connected to SIG+
- Pin 6 connected to SIG-
- Pin 7 connected to the Shield


4-2 INDICATOR INSTALLATION AND DIMENSIONS

2 The indicator can be installed in a control panel as detailed below





2 INDICATOR DIMENSIONS (measurement unit: mm)





CHAPTER 5 CAPACITY CALIBRATION


5-1 PARAMETER SETTING

Switch the capacity calibration switch to “ON” and the display shows **SEt**.

Press the **F11** key and the display shows **PAR.** then enter the setting mode.

Refer to 3-1 Front Panel for the key functions to set the relative parameters.

5-1-1 Flow Diagram





5-1-2 Description

1) Decimal Point

Setting the weight decimal point position, with the following options: 0, 0.0, 0.00, 0.000, 0.0000.

2) Max. Capacity

Depending on the decimal point position, the max capacity can be set from 99.999 to 999999.

3) Min. Division

Depending on the decimal point position and the max capacity, the min. division could be set as 1, 2, 5, 10, 20, 50.

4) Zero Tracking

| Display | Division / Time |
|--------------|------------------|
| a.t.r. 1.0-1 | 1 D / 1 sec |
| a.t.r. 2.0-1 | 2 D / 1 sec |
| a.t.r. 3.0-1 | 3 D / 1 sec |
| a.t.r. 4.0-1 | 4 D / 1 sec |
| a.t.r. 1.0-2 | 1 D / 2 sec |
| a.t.r. 2.0-2 | 2 D / 2 sec |
| a.t.r. 3.0-2 | 3 D / 2 sec |
| a.t.r. 4.0-2 | 4 D / 2 sec |
| a.t.r. no | No zero tracking |



5) Unstable Detection

| Display | Division / Time |
|----------|-----------------|
| n̄o.d 1d | 1 d / sec |
| n̄o.d 2d | 2 d / sec |
| n̄o.d 3d | 3 d / sec |
| n̄o.d 4d | 4 d / sec |
| n̄o.d 5d | 5 d / sec |
| n̄o.d no | No detection |




5-2 CALIBRATION SETTING

Please allow the indicator to warm up at least 15 to 30 minutes before calibration.

Switch the capacity calibration switch to “ON” and the display shows **SEt**.

Press the **CAL** key and the display shows **00 CAL** . then enter the setting mode.

5-2-1 Calibration Procedure



5-2-2 Zero Calibration

a) Make sure that there are no objects on the weighing platform and press the **ENTER** key, after the indicator has stabilized the display will show “ ”. The calibration is completed after about 5 seconds.

b) To skip the “Zero calibration” procedure, press the **STANDBY/OPERATE** key.

5-2-3 Weight Calibration


a) Place an accurate weight onto the platform; use the front panel keys to key in the weight value. Press the **ENTER** key, after the indicator is stabilized the display will show “ ”. The calibration is completed after about 5 seconds.

b) To skip the weight calibration, press the **STANDBY/OPERATE** key.



5-2-4 Linearity Calibration

Before linearity calibration, make sure “Zero calibration” and “Weight Calibration” are properly performed. Set the calibration switch to ON position.



After finishing the first linearity calibration, choose to continue or exit the linearity mode


by pressing **STANDBY OPERATE**.

◆ Refer to 5-4 Error Messages when any error message appears during the procedure.



Recall Linearity correction point

Set the calibration switch to ON position.




| | |
|--|---|
| | ⇒ Increase the number of the flashing digit |
| | ⇒ Decrease the number of the flashing digit |
| | ⇒ Shift the flashing digit one space to left |
| | ⇒ Shift the flashing digit one space to right |
| | ⇒ Save the settings |
| | ⇒ Exit the settings |



Clear a linearity correction point

Set the calibration switch to ON position.




After finishing the first linearity calibration, users can choose to continue or exit the linearity mode by pressing **STANDBY OPERATE**.

| | |
|------------------------|---|
| ZERO + | ⇒ Increase the number of the flashing digit |
| TARE - | ⇒ Decrease the number of the flashing digit |
| GROSS NET ← | ⇒ Shift the flashing digit one space to left |
| PRINT → | ⇒ Shift the flashing digit one space to right |
| ENTER ↵ | ⇒ Save the settings |
| STANDBY OPERATE | ⇒ Exit the settings |



5-3 PASSWORD SETTING

Set the calibration switch to ON position.



| | |
|--|---|
| | ⇒ Increase the number of the flashing digit |
| | ⇒ Decrease the number of the flashing digit |
| | ⇒ Shift the flashing digit one space to left |
| | ⇒ Shift the flashing digit one space to right |
| | ⇒ Save the settings |
| | ⇒ Exit the settings |

- 4 Once the password is set, whenever users access to the calibration mode or the other function settings, the display shows After 1 sec. → , and users need to enter the password.
- 4 If the password is incorrect, is displayed.




5-4 ERROR MESSAGES

- (1) Err 0 The output voltage of load cell is $< - 0.1\text{mV/V}$ or $> 4\text{mV/V}$
- (2) Err 1 The weight setting value is not over the setting value of prior section.
- (3) Err 2 The actual weight value is not over the value of prior section.
- (4) Err 3 The setting value is 0.
- (5) Err 6 Calibration resolution is less $0.12\mu\text{V} / \text{d}$.
- (6) Err. Incorrect password



CHAPTER 6 ANIMAL SCALE FUNCTION SETTING


2 FUNC. 8 = 1 (Animal scale function is active)

“” is displayed, when there is no object on the weight panel:



The weight of live stocks is measured and showed in the display, (20 kg in this example):



The weight value will be held until removing all the objects on the weight panel. When the weight value is below zero band and display shows “”, the scale is ready for another weighing operation.





CHAPTER 7 INTERFACES

7-1 OP-01 RS-422 & RS-485 INTERFACE


2 OP-01 RS-422 / RS-485

With this interface up to 10 indicators can be connected together and data transferred to a host controller.

FUNC. 70 should be set to “ 1 ”

2 Connector pin assignment

REAR PANEL




| Pin number | Function |
|------------|----------|
| 1 | SDA |
| 2 | SDB |
| 3 | RDA |
| 4 | RDB |
| 5 | TRM |
| 6 | SG |
| 7 | |
| 8 | |
| 9 | RDB' |




2 Connection method

RS-422



RS-485



4 Remark:


When connecting the last EX-2001 indicator, the fifth pin (TRM) and the ninth pin (RDB') should be connected together, excluding the following two conditions:-

- ◆ The host computer has a built-in terminator.
- ◆ The host computer does not have signal ground (SG).



2 Refer to Chapter 9 Function Table to set FUNC. 60 ~ FUNC. 67

2 Transmit format



Header 1

ST : Stable / US : Unstable / OL : Over Load

Header 2

GS : Gross weight / NT : Net weight / TR : Tare

Weight Data (8 digits)

The first digit is the + / - symbol for weight value. The next seven digits include decimal point and weight value.

When the weight is over loaded (Header 1 : OL), all digits will be transmitted "blank" (sp) except the + / - signal and the decimal point.

Units

Kg, g, t, lb or "blank"

Terminators

CR, LF is the data finish code.

2 Command mode

| COMMAND | FUNCTION |
|----------|-----------------------------|
| READ, RW | Reads weight |
| ZERO, MZ | Back to zero |
| TARE, MT | Tare |
| NTGS | Switches gross / net weight |
| MG | Displays gross weight |
| MN | Displays net weight |
| CT | Clears tare |

- Ⓔ The command string must be terminated with CR (0DH) , LF (0AH) .
- If a wrong command is received, the indicator will reply "E" + " error command " .
- ⌘ If the command mode has been selected "with address", (FUNC. 61 = 4) then every command must be preceded with an indicator address in the format:-
" @ address "

Example: To read the weight value form indicator addressed as 01 ("01" selected in FUNC. 67)


The complete command is **@01RW<CR><LF>**



7-2 OP-02 PARALLEL BCD OUTPUT

2 Pin assignment

REAR PENAL




BCD parallel output interface
uses Centronic 50 PIN connector

| Pin number | Function | Pin number | Function |
|------------|-------------------|------------|-------------------|
| 1 | SG | 26 | SG |
| 2 | 1×10 | 27 | Gross/-NET |
| 3 | 2×10 | 28 | |
| 4 | 4×10 | 29 | |
| 5 | 8×10 | 30 | |
| 6 | 1×10 ¹ | 31 | |
| 7 | 2×10 ¹ | 32 | |
| 8 | 4×10 ¹ | 33 | Stable |
| 9 | 8×10 ¹ | 34 | |
| 10 | 1×10 ² | 35 | |
| 11 | 2×10 ² | 36 | |
| 12 | 4×10 ² | 37 | |
| 13 | 8×10 ² | 38 | |
| 14 | 1×10 ³ | 39 | |
| 15 | 2×10 ³ | 40 | |
| 16 | 4×10 ³ | 41 | |
| 17 | 8×10 ³ | 42 | POSITIVE |
| 18 | 1×10 | 43 | DP10 ¹ |
| 19 | 2×10 | 44 | DP10 ² |
| 20 | 4×10 | 45 | DP10 ³ |
| 21 | 8×10 | 46 | DP10 |
| 22 | 1×10 | 47 | OVER |
| 23 | 2×10 | 48 | |
| 24 | 4×10 | 49 | Data ready |
| 25 | 8×10 | 50 | Hold input |




2 Refer to Chapter 9 Function Table to set FUNC. 80 ~ FUNC. 83

2 Output equivalent circuit




2 Hold Input



2 Output / Input signal description


- ☒ A total of 33 bit outputs are provided. To set the output logic level, refer to Chapter 9 FUNC 82 and FUNC 83.
- If Open Collector output is selected, an external resistor is required to limit the current in the interface. The voltage should not exceed 30Vdc and current should be less than 30mA.
- ☒ “Hold input” is the only one input signal. To activate the “Hold input”, just connect the Hold input to SG signal. When Hold is working, all BCD outputs will be held and cannot be altered.





7-3 OP-03 ANALOGUE CURRENT / VOLTAGE OUTPUT INTERFACE

2 Connections





Interface specification

Analogue current output : 0 ~ 20 mA
 Load resistor : 0 ~ 550 Ω
 Resolution : 12 bit

2 Refer to Chapter 9 Functions Table to set FUNC 85 ~ FUNC 89

2 Voltage output


J1 short if the voltage output is 0 ~ 10V.
 J1 open if the current output is 4 ~ 20mA.





7-4 OP-05 PARALLEL PRINTER OUTPUT & RS-232 & CURRENT LOOP

2 Pin assignment



| Pin number | Function | Pin number | Function |
|------------|----------------------------|------------|---------------------------|
| 1 | $\overline{\text{STROBE}}$ | 14 | NC |
| 2 | D0 | 15 | $\overline{\text{ERROR}}$ |
| 3 | D1 | 16 | $\overline{\text{INIT}}$ |
| 4 | D2 | 17 | NC |
| 5 | D3 | 18 | SG |
| 6 | D4 | 19 | SG |
| 7 | D5 | 20 | SG |
| 8 | D6 | 21 | SG |
| 9 | D7 | 22 | SG |
| 10 | $\overline{\text{ACK}}$ | 23 | SG |
| 11 | BUSY | 24 | SG |
| 12 | NC | 25 | SG |
| 13 | NC | | |

2 Refer to Chapter 9 Functions Table to set FUNC 90 ~ FUNC 99

2 RS-232 pin position

| Pin number | Function | Pin number | Function |
|------------|----------|------------|----------|
| 1 | TXD | 3 | C. LOOP1 |
| 2 | SG | 4 | C. LOOP2 |

2 Refer to Chapter 9 Functions Table to set FUNC. 60, 62, 63, 64



2 Print format

Format 1 (FUNC. 90=0)

FUNC. 95 ≠ 0 ⇒ Print "SN" value

DATE : 2004/08/30
 TIME : 12:13:36
 SN. : 1
 GROSS : 11.5 kg
 TARE : 1.5 kg
 NET : 10.0 kg

FUNC. 95 = 0 ⇒ No "SN" value

DATE : 2004/08/30
 TIME : 12:13:36
 GROSS : 11.5 kg
 TARE : 1.5 kg
 NET : 10.0 kg

Format 2 (FUNC. 90=1)

Material : 0
 DATE : 2004/08/30

| SN. | TIME | NET(kg) |
|-----|----------|---------|
| 1 | 12:14:39 | 11.5 |
| 2 | 12:14:45 | 6.5 |

SUB TOTAL

DATE : 2004/08/30
 COUNT : 2
 NET : 18.0 kg

| | | |
|---|----------|-----|
| 3 | 12:14:57 | 8.0 |
|---|----------|-----|

SUB TOTAL

DATE : 2004/08/30
 COUNT : 1
 NET : 8.0 kg

GRAND TOTAL

DATE : 2004/08/30
 COUNT : 3
 NET : 26.0 kg

Format 3 (FUNC. 90=2)

| SN. | DATE | TIME | GROSS (kg) | TARE (kg) | NET (kg) |
|-------------|------------|----------|------------|-----------|----------|
| 1 | 2004/08/30 | 12:16:19 | 7.0 | 2.0 | 5.0 |
| 2 | 2004/08/30 | 12:16:31 | 7.0 | 2.0 | 5.0 |
| SUB TOTAL | | | | | 10.0 |
| 3 | 2004/08/30 | 12:17:00 | 12.0 | 7.0 | 5.0 |
| 4 | 2004/08/30 | 12:17:19 | 12.0 | 7.0 | 5.0 |
| GRAND TOTAL | | | | | 20.0 |



Format 4 (FUNC. 90=3)

EZ-2 print format

FUNC. 95 ≠ 0 ⇒ Print "SN" value

FUNC. 95 = 0 ⇒ No "SN" value

| | |
|---------------------|-----------------|
| 2004/11/26 | 08:53:05 |
| SN. : 1 | |
| GROSS : 5.00 | |
| TARE : 0.00 | |
| NET : 5.00 | |

| | |
|---------------------|-----------------|
| 2004/11/26 | 08:53:05 |
| GROSS : 5.00 | |
| TARE : 0.00 | |
| NET : 5.00 | |

25 mm
Label Width

2 mm
Label Space

| | |
|---------------------|-----------------|
| 2004/11/26 | 08:52:05 |
| SN. : 1 | |
| GROSS : 5.00 | |
| TARE : 0.00 | |
| NET : 5.00 | |

| | |
|---------------------|-----------------|
| 2004/11/26 | 08:52:05 |
| GROSS : 5.00 | |
| TARE : 0.00 | |
| NET : 5.00 | |


25 mm
Label Width



7-5 OP-06 RS-232 & CURRENT LOOP

2 RS-232 / Current Loop

RS-232C is a bi-directional output/input; Current Loop is one-way output only, and the output data format is the same as RS-232.






7-6 OP-07 RS-232, CURRENT LOOP & DATA CLOCK OUTPUT


2 RS-232 / Current Loop

RS-232C is a bi-directional output/input; Current Loop is one-way output only, and the output data format is the same as RS-232.




2 Data Clock serial output

FUNC. 70 should be " 0 "



| Pin Position | Function |
|--------------|----------|
| 1 | + 5V |
| 2 | DATA |
| 3 | CLK |
| 4 | GND |

Inner Connection






7-7 OP-08 CONTROL I / O (2I /4O) INTERFACE

2 External input and relay output


CONTROL IN / OUTPUT




Output Pin Function

- 1 : Zero Band
- 2 : Hi
- 3 : Ok
- 4 : Lo

Input / output connectors on the rear panel




The output circuit of Relay



The input circuit




2 HI , OK , LO Output Procedure












2 The Flow Chart of HI , OK , LO Setting


Press and hold , followed by pressing , to enter the check weighing mode.



Key in the “High Limit Value” by using the keys described at the right hand side.

Press  key to complete the setting and go to the next step






| | |
|---|---|
|  | ⇒ Increase the number of the flashing digit |
|  | ⇒ Decrease the number of the flashing digit |
|  | ⇒ Shift the flashing digit one space to left |
|  | ⇒ Shift the flashing digit one space to right |
|  | ⇒ Save the settings |
|  | ⇒ Exit the settings |









CHAPTER 8 MAINTENANCE








8-1 RESET ALL PARAMETERS BACK TO DEFAULT

- (1) Switch the capacity calibration switch to “ON”, press and hold   keys together when the indicator is in the self-testing sequence.
- (2) The display shows 
- (3) Press and hold the  key until the display shows . Switch the calibration switch to “OFF”.

8-2 RESET GENERAL FUNCTION PARAMETERS BACK TO DEFAULT

- (1) When the indicator reset back to zero, press and hold   keys. The indicator is in the self-testing sequence.
- (2) The display shows 
- (3) Press and hold the  key until the indicator resets.

8-3 SELF-DIAGNOSIS MODE

- (1) When the indicator reset back to zero, press and hold   keys. The indicator is in the self-testing sequence.
- (2) When the display shows  , it means the indicator is already in the Self-diagnosis mode.
- (3) Press  and  keys to select a diagnosis item. Press the  key to enter the selected item for diagnosis and press  to exit.



| No. | Display | Diagnosis Item |
|-----|---------|--|
| 1 | dSP | 7 digits display and LED status lights |
| 2 | KEY | Keyboard and calibration ON / OFF switch |
| 3 | 232 | OP-06 RS-232 serial output / input interface |
| 4 | bCd | OP-02 BCD parallel output interface |
| 5 | AnL | OP-03 Analogue current output interface |
| 6 | Par | OP-05 Parallel printer interface |
| 7 | EEP | EEPROM memory on main board |
| 8 | IO - io | OP-08 Control I/O interface |

8-3-1 7 Digit Display and LED Status Light Diagnosis

7 digit display shows 0 ~ 9, "." And at the same time, the LED status lights turn on and off in order.

8-3-2 Keyboard and Calibration ON / OFF Switch Diagnosis

Switch the calibration switch to "ON", or press any keys and the corresponding digit goes from 1 → 1 on the display.

8-3-3 RS-232 Serial Output / Input Interface Diagnosis (OP-06)

(1) Short circuit the 2nd pin and 3rd pin of the SER. OUT. D-SUB 25 pin connector.

PASS = Working properly FAIL = Malfunction

(2) If connecting to a computer (The communication protocol has to be compatible),

if 0 ~ 9 can be read, it indicates that the RS-232 is in working order.

8-3-4 BCD Parallel Output Interface Diagnosis (OP-02)

(1) The decimal point flashes during the diagnosis.

(2) The program sends out OFF→ON→OFF signals from each of BCD output bit.

(3) If no - IF is displayed, this indicates that no BCD interface is installed.



8-3-5 Analogue Current Output Interface Diagnosis (OP-03)

(1) Use  and  keys to select output current.

(a) **AnL 4** : 4mA


(b) **AnL 12** : 12mA

(c) **AnL 20** : 20mA

(2) If **no - IF** is displayed, this indicates that an interface has not been installed.

8-3-6 Parallel Printer Interface Diagnosis (OP-05)

(1) Connect the interface to the printer.

(2) Press the  key and the printer will print date, time and ASCII code as 30H ~ 7AH characters or figures.

(3) If **Err** is displayed, this indicates that the printer or the interface is not working properly.


(4) If **no - IF** is displayed, the interface is not connected to the indicator.

8-3-7 Main Board EEPROM Memory Diagnosis

PASS = Working properly

FAIL = Malfunction

8-3-8 OP-08 Control I/O (2I/4O) Diagnosis






CHAPTER 9 FUNCTION TABLE

9-1 GENERAL FUNCTION


| FUNC. NO. | FUNCTION | SET VALUE | | DEFAULT |
|-----------|--|--|---|---------|
| FUNC. 0 | Tare and Zero function when the weight is unstable | 0 | ON | 0 |
| | | 1 | OFF | |
| FUNC. 1 | Tare function with negative gross weight | 0 | ON | 0 |
| | | 1 | OFF | |
| FUNC. 2 | Key function | 0000 ↓ 1111 | 0 ON 1 OFF | 0000 |
| | | 0000 corresponding keys from left to right are | | |
| FUNC. 3 | Auto Zero function after power on | 0 | OFF | 0 |
| | | 1 | ON | |
| FUNC. 4 | Zero range | 0D ↓ 9D | When the weight is in this range $\pm(\text{Set value} \times \text{Min. division})$ it displays "0" | 0 |
| FUNC. 5 | Weighing Filter | 0 ↓ 5 | The larger the value the greater the amount of filtering. When set to 0, the filter will adjust automatically. | 2 |
| FUNC. 6 | A/D sampling frequency | 0 | Unlimited | 2 |
| | | 1 | 20 times/sec | |
| | | 2 | 10 times/sec | |
| | | 3 | 5 times/sec | |
| FUNC. 7 | Display update rate | 0 | Unlimited | 1 |
| | | 1 | 20 times/sec | |
| | | 2 | 10 times/sec | |
| | | 3 | 5 times/sec | |
| | | 4 | 1 times/2sec | |
| FUNC. 8 | Animal scale | 0 | OFF | 0 |
| | | 1 | ON | |



9-2 OP-01, OP-06, OP-07 INTERFACE FUNCTION

| FUNC. NO. | FUNCTION | SET VALUE | | | DEFAULT | |
|-----------|------------------------------------|---------------|---|--|---------|--|
| | | PARAMETER | DESCRIPTION | | | |
| FUNC. 60 | Data type | 0 | As displayed | | 0 | |
| | | 1 | Gross | | | |
| | | 2 | Net | | | |
| | | 3 | Tare | | | |
| FUNC. 61 | Transmit mode | 0 | Stream transmit | | 0 | |
| | | 1 | Auto-transmit | | | |
| | | 2 | Press  key to transmit | | | |
| | | 3 | Command mode (without address) | | | |
| | | 4 | Command mode (with address) | | | |
| FUNC. 62 | BAUD rate | 0 | 1200 | | 1 | |
| | | 1 | 2400 | | | |
| | | 2 | 4800 | | | |
| | | 3 | 9600 | | | |
| | | 4 | 19200 | | | |
| FUNC. 63 | Parity bit Data bit Stop bit | 0 | N, 8, 1 | No parity bit, 8 data bit, 1 stop bit | 2 | |
| | | 1 | O, 7, 1 | Odd parity bit, 7 data bit, 1 stop bit | | |
| | | 2 | E, 7, 1 | Even parity bit, 7 data bit, 1 stop bit | | |
| FUNC. 64 | Units | 0 | None | | 1 | |
| | | 1 | kg | | | |
| | | 2 | g | | | |
| | | 3 | t | | | |
| | | 4 | lb | | | |
| FUNC. 65 | Unstable or over the max. capacity | 0 | Continuous output | | 0 | |
| | | 1 | Stop output | | | |
| FUNC. 66 | Auto-transmit conditions | 0 | Positive (more than + 5D) | | 0 | |
| | | 1 | Positive / negative (more than + 5D, less than - 5D) | | | |
| FUNC. 67 | Command address | 00 ↓ 99 | When the FUNC. 61 is set in 4, it will use this address | | 0 | |
| FUNC. 68 | Output format | 0 | Standard Format | | 0 | |
| | | 1 | UMC 600 | | | |
| FUNC. 69 | Transmit frequency | 0 | W/o limit | | 4 | |
| | | 1 | 1 Time/ Sec. | | | |
| | | 2 | 2 Times/ Sec. | | | |
| | | 3 | 5 Times/ Sec. | | | |
| | | 4 | 10 Times/ Sec. | | | |
| | | 5 | 20 Times/ Sec. | | | |
| FUNC. 70 | Output type | 0 | Close RS422/485 | | 0 | |
| | | 1 | Start RS422/485 | | | |

**9-3 OP-02 BCD OUTPUT INTERFACE FUNCTION**




| FUNC. NO. | FUNCTION | SET VALUE | | DEFAULT |
|-----------|-------------------|-----------|--|---------|
| | | PARAMETER | DESCRIPTION | |
| FUNC. 80 | Data type | 0 | As displayed | 0 |
| | | 1 | Gross | |
| | | 2 | Net | |
| FUNC. 81 | Transmit mode | 0 | Stream transmit | 0 |
| | | 1 | Auto-transmit | |
| | | 2 | Press the  key to transmit | |
| FUNC. 82 | Output data logic | 0 | Positive logic | 0 |
| | | 1 | Negative logic | |
| FUNC. 83 | Signal logic | 0 | Positive logic | 0 |
| | | 1 | Negative logic | |

9-4 OP-03 ANALOGUE OUTPUT INTERFACE FUNCTION

| FUNC. NO. | FUNCTION | SET VALUE | | DEFAULT |
|-----------|-----------------------------------|------------------------|--|---------|
| | | PARAMETER | DESCRIPTION | |
| FUNC. 85 | Data type | 0 | As displayed | 0 |
| | | 1 | Gross | |
| | | 2 | Net | |
| FUNC. 86 | Low point of weight value | 000000 ↓ 999999 | When the weight value reaches the value set in Func. 86, the current output is the value set in Func. 87 | 0 |
| FUNC. 87 | Low point of output current value | 0.0 mA ↓ 20.0 mA | | 4.0 mA |
| FUNC. 88 | High point Weight value | 000000 ↓ 999999 | When the weight value reaches the value set in Func. 88, the current output is the value set in Func. 89 | 16000 |
| FUNC. 89 | High point Output current value | 0.0 mA ↓ 20.0 mA | | 20.0 mA |



9-5 OP-05 PARALLEL PRINTER OUTPUT INTERFACE FUNCTION

| FUNC. NO. | FUNCTION | SET VALUE | | DEFAULT |
|-----------|-----------------------------------|---------------------------|--|---------|
| | | PARAMETER | DESCRIPTION | |
| FUNC. 90 | Data format | 0 â | Select print format | 0 |
| FUNC. 91 | Transmit mode | 0 | Press the  to transmit | 0 |
| | | 1 | Auto / press  to transmit | |
| FUNC. 92 | The size of left hand side margin | 0 ~ 80 (characters) |  <p>TIME: 14:20:30 GROSS: 23.5kg</p> <p>TIME: 15:30:20 GROSS: 21.0kg</p> | 0 |
| FUNC. 93 | The space between blocks of data | 0 ~ 80 (LF) | | 5 |
| FUNC. 94 | Material number | 000000 â 999999 | When printing the material number, it keeps the same value as previously set. | 0 |
| FUNC. 95 | Serial number | 00000 â 65535 | When printing the serial number, it automatically increments. It resets to 00000 after restarting the indicator or after printing out the total weight. | 1 |
| FUNC. 96 | Units | 0 | None | 1 |
| | | 1 | kg | |
| | | 2 | g | |
| | | 3 | t | |
| | | 4 | lb | |
| FUNC. 98 | Date setting | 2000 yr. â 2099 yr. | | |
| FUNC. 99 | Time setting | 00:00:00 â 23:59:59 | | |

**9-6 OP-08 CONTROL I /O (2I /4O) INTERFACE FUNCTION**

| FUNC. NO. | FUNCTION | SET VALUE | | DEFAULT |
|-----------|---|-------------------|--|---------|
| | | PARAMETER | DESCRIPTION | |
| FUNC. 50 | Input 1 | 0 ⇒ 1 ⇒ 2 ⇒ | No capacity Zero Tare | 1 |
| FUNC. 51 | Input 2 | 3 ⇒ 4 ⇒ | Clear Tare judgment_comm_flag | 2 |
| FUNC. 52 | Output logic | 0000 | Positive logic | 0000 |
| | | 1111 | Negative logic | |
| FUNC. 53 | Hi,OK,Lo Check weighing mode | 0 | Comparison occurs at any time | 0 |
| | | 1 | Comparison occurs after inputting external judgment signal | |
| | | 2 | Auto comparison | |
| FUNC. 54 | Comparison mode | 0 | General comparison + | 0 |
| | | 1 | Absolute value only comparison +/- | |
| FUNC. 55 | Lead time setting for activating comparison | 0.0 ↓ 25.5 | Lead time setting for inputting external judgment signal | 0.5 |